
# ActiveReach<sup>™</sup> power positioning checklist

#### □ Full range of power seat functions



ActiveReach can be programmed with a custom sequence that works for your body and your daily needs.

#### Your world within reach

- □ Customizable ActiveReach sequences\*
- □ Programmable footplate height in ActiveReach<sup>\*</sup>
- □ Drive at walking speeds while fully elevated
- $\hfill\square$  Drive while in ActiveReach
- □ Independently adjustable backrest and legrest angles in ActiveReach position

Ensure that the adjustability, stability and drive speeds in both seat elevation and ActiveReach will be functional for your daily life.

### Quality from the ground up

- $\hfill\square$  Base stability in sitting and ActiveReach positions
- □ Active suspension in all positions
- □ Bright, functional LED lighting included with a four-function chair
- □ Dedicated cable paths for cable protection & reliability

A solid foundation is key to stability, this is especially true in the ActiveReach and/or ActiveHeight positions. Make sure your wheelchair was designed from the beginning with these positions in mind.

### Easily find your perfect position

- □ Save and recall memory seat positions
- □ Activate a preferred position in a way that works for you with programmable buttons on the joystick
- □ Smart actuators allow for display of live seat angles within MyPermobil app for real time seat position feedback
- □ 10° of ActiveReach included for no additional charge with ActiveHeight seat elevation

Your power seat functions should be programmable to provide you the best possible positioning in both sitting and ActiveReach.

Notes: \_



For justification assistance & funding resources, please email us at **US\_Funding@Permobil.com** or visit **PermobilLMN.com**.

\*Available with Permobil ActiveReach packages of 20 degrees or more.

## permobil